



INSTALLATION GUIDE

APPLICATION, CARE, & REMOVAL

TOOLS REQUIRED

- ✓ APPLICATION SOLUTION***
- ✓ GLASS CLEANER [ammonia-free]
- ✓ LINT-FREE CLOTH
- ✓ SQUEEGEE [included]

*** Please see reverse for instructions on making your own solution ***

APPLICATION

1 CLEAN DISPLAY WITH GLASS CLEANER + LINT-FREE CLOTH

All debris must be completely removed from the display and surrounding edge.


2 SPRAY & PEEL

To avoid fingerprints, spray fingers with solution before peeling the shield from the liner. Lightly spray the display surface and the shield's adhesive backing to allow movement on the display. Place the shield on the display.

3 POSITION ON DISPLAY

Gently slide the shield until centered, leaving an even gap between the shield edges and the display border (about 1/16" all around).

4 SQUEEGEE TO SECURE SHIELD



Spray solution on shield surface for extra lubrication. Starting at the top-center (#1), squeegee toward outside edges, following the pattern illustrated to the left.

PRO TIP:

Repeat squeegee process 2-3 times in slow, overlapping strokes as pictured, increasing pressure with each repetition.

5 ABSORB EXCESS SOLUTION

Wrap squeegee in cloth and firmly "bump" edges to seal adhesive. Wipe away any remaining solution. SEE REVERSE FOR DRYING TIME AND CARE INSTRUCTIONS.

QUESTIONS? WE'RE HERE TO HELP.

1-800-833-1566 / SERVICE@DISPENSERSHIELD.COM

APPLICATION SOLUTION

Fill a 32 oz. spray bottle with bottled/filtered water (not tap water) and add 1-2 small drops of JOHNSONS® Baby Shampoo OR mild liquid dish soap.

DRYING TIME

After application, there may be a temporary haze or small bubbles remaining. This will disappear as the adhesive dries and should not impair visibility.
Outdoor Dry Time: 2-3 days / Indoor Dry Time: 4 - 7 days.

MAINTENANCE & CARE

Do NOT clean the shields for at least 5 days after application to allow proper bonding of the shield's adhesive to the substrate.
Use soft, non-abrasive cloths and gentle cleaners such as ammonia-free Windex®. Avoid industrial strength chemicals such as acetone and ammonia.

GRAFFITI REMOVAL TIPS

SCRATCHES / CARVING

Once the shield has sustained severe damage, simply peel it away and replace.

PAINT OR MARKET PENS

Freshly inked graffiti can be wiped away with soapy water (or diluted alcohol with water). Rinse the shield surface with water when finished.

ACID-ETCHING

Carefully rinse the shield surface and surrounding areas with water to prevent the acidic chemicals from spreading to unprotected surfaces nearby.

Safety Precautions: Avoid direct contact with eyes or skin. Wear long sleeves, rubber/plastic gloves, and protective eye wear when handling acid-etch. For emergency information, please call the Poison Control Center: 1-800-222-1222.

SHIELD REMOVAL

Before removal, clean the exposed display surface and surrounding edge to minimize debris during placement. Use the Dispenser Shield® Tool to apply pressure at a corner edge to break the adhesive bond. Once the corner is lifted, shields can be peeled away by hand, residue-free.

Avoid using sharp tools during removal, as these may damage the substrate.

NEITHER SELLER NOR MANUFACTURER SHALL BE LIABLE FOR ANY INJURY, LOSS OR DAMAGE, DIRECT OR CONSEQUENTIAL, ARISING DURING APPLICATION, USE, OR REMOVAL OF DISPENSER SHIELD® PRODUCTS.

